

# GenElute™-E Viral Spin Column Checklist



## Prepare before starting

- Vortex GenElute™-E spin column and place in a 2 mL tube.
- Let stand for 15 minutes.
- Loosen screw cap of spin column.
- Snap off bottom closure. Place spin column back into 2 mL tube.
- Centrifuge 1 minute at 1,000 x g to collect column buffer.
- Place column in a 1.5 mL tube.



## Lysis and Recovery of Viral Nucleic Acids

- Add 50 µL of Viral SmartLyse™ Viral Buffer to 1.5 mL tube for sample preparation.
  - Optional:** Add 1-20 µL of internal control (IC) provided by user. ICs that are added before the purification step should be > 500 nucleotides in length.
- Preparing sample
  - Swabs in transport media: Transfer 50 µL of swab media to the 1.5 mL tube with SmartLyse™ Viral Buffer.
  - Dry Swabs: Dilute the viral particles by rinsing the swab in 300-700 µl PBS of pH 7.2-8.5. Transfer 50 µL of sample to the 1.5 mL tube with SmartLyse™ Viral Buffer.
  - Stool samples: In a 2.0 mL tube add 10-20 mg stool sample and keep on ice. Resuspend in 600 µL 50 mM Tris buffer or PBS of pH 7.2-8.5. Transfer 50 µL of solution to the 1.5 mL reaction tube containing SmartLyse™ Viral Buffer.
- Transfer 90 µL of sample solution to prepared columns.
- Centrifuge 1 minute at 1,000 x g to collect Viral RNA/DNA.
- Collected Viral RNA/DNA is ready to use



The life science business of Merck KGaA, Darmstadt, Germany operates as MilliporeSigma in the U.S. and Canada.

Merck, GenElute, SmartLyse and Sigma-Aldrich are trademarks of Merck KGaA, Darmstadt, Germany or its affiliates. All other trademarks are the property of their respective owners. Detailed information on trademarks is available via publicly accessible resources.  
© 2021 Merck KGaA, Darmstadt, Germany and/or its affiliates. All Rights Reserved.

20598313w-CL Rev 09/21 spin column