

Quick Start Guide

GenElute™ HP Select Plasmid Gigaprep Kit

NA0800

Reagents to Prepare

- Add 3.0 mL of RNase A Solution to the Resuspension Solution. Store at 2-8 °C.
- Add 800 mL of 95-100% ethanol to the larger bottle (200 mL size) of Wash Solution 2; should additional quantities be needed, 300 mL of 95-100% ethanol can be added to the smaller bottle (75 mL size) of Wash Solution 2. After each use, tightly cap the diluted Wash Solution to prevent ethanol evaporation.

Protocol

Vacuum format.

Harvest Bacteria

1. Pellet cells from 2000 mL overnight culture by spinning for 10 min at 5,000 x g. Discard supernatant.

Prepare Column

2. Place Column onto a 45 mm neck bottle (1000 mL).
3. Add 100 mL of Column Preparation Solution to column, apply vacuum and allow it to pass through.

Resuspend and Lyse Bacteria

4. Resuspend cells in 100 mL Resuspension Solution. Pipet or vortex to mix.
5. Add 100 mL Lysis Solution. Gently invert 10-12 times to mix. Do not vortex. Allow to clear for 3-5 min.

Prepare Cleared Lysate

6. Add 100 mL Neutralization Solution (chilled prior to use) to the lysed cells and gently shake 10-12 times to mix.
7. Empty entire bag of Lysate Clearing Agent into lysate and gently shake several times to mix. Incubate 5 min at room temperature.
8. Attach the Lysate Filter to a 45 mm neck bottle (≥500 mL).
9. Add lysate to assembled Lysate Filter and apply vacuum to clear cell debris.
10. Add 100 mL Binding Solution to the bottle containing the cleared lysate and swirl to mix.

Bind DNA to Column

11. Add cleared lysate to prepared column, apply vacuum and allow all lysate to pass through.

Wash to Remove Contaminants

12. Add 40 mL EndoCleaning Solution to column and allow it to pass through.
13. Add 150 mL Wash Solution 1 to the column and allow it to pass through.
14. Add 200 mL Wash Solution 2 to column and allow it to pass through.
15. Leave vacuum on for 25-35 min to dry the column.

Elute Purified DNA

16. Attach Column to another sterile Endo-Free 45 mm neck bottle (150-250 mL).
17. Add 30 or 50 mL Endotoxin-Free Water to column, wait 1-2 min and apply vacuum for 2-3 min.

Notice

We provide information and advice to our customers on application technologies and regulatory matters to the best of our knowledge and ability, but without obligation or liability. Existing laws and regulations are to be observed in all cases by our customers. This also applies in respect to any rights of third parties. Our information and advice do not relieve our customers of their own responsibility for checking the suitability of our products for the envisaged purpose.

The information in this document is subject to change without notice and should not be construed as a commitment by the manufacturing or selling entity, or an affiliate. We assume no responsibility for any errors that may appear in this document.

Contact Information

For the location of the office nearest you, go to SigmaAldrich.com/Offices.

Technical Assistance

Visit the tech service page on our web site at SigmaAldrich.com/TechService.

Standard Warranty

The applicable warranty for the products listed in this publication may be found at SigmaAldrich.com/Terms.

MilliporeSigma, Millipore, GenElute and Sigma-Aldrich are trademarks of Merck KGaA, Darmstadt, Germany or its affiliates. All other trademarks are the property of their respective owners. Detailed information on trademarks is available via publicly accessible resources.
© 2022 Merck KGaA, Darmstadt, Germany and/or its affiliates. All Rights Reserved.

The life science business of Merck KGaA, Darmstadt, Germany operates as MilliporeSigma in the U.S. and Canada.